

LINE/LINEA VOLKSWAGEN - FUSCA				
IGP	OEM	DESCRIPTION	DESCRIPCIÓN	APLICACION/APLICACIÓN
14	111.701.475.A	JACKING POINT SUPPORT	SOPORTE DEL GATO	FUSCA
16	113.805.591.Z	CENTRAL FRONT PANEL	PANEL DELANTERO CENTRAL	FUSCA - 1200 - .../70
17	113.813.301.ZC	CENTRAL REAR PANEL	PANEL TRASERO CENTRAL	FUSCA - 1200 - .../70
18	113.809.086	FRONT INNER CASTING - RH	LATERAL DELANTERA INT. - DER.	FUSCA - .../76
19	113.809.085	FRONT INNER CASTING - LH	LATERAL DELANTERA INT. - IZQ.	FUSCA - .../76
20	113.809.022.13	FRONT INNER CASTING - RH	LATERAL DELANTERA INT. - DER.	FUSCA - 77/...
21	113.809.021.10	FRONT INNER CASTING - LH	LATERAL DELANTERA INT. - IZQ.	FUSCA - 77/...
29	113.701.311.1	HEAD'S BASE OF CHASSIS 1200/1300	BASE DEL CABEZOTE - 1200/1300	FUSCA - 1200/1300
30	113.701.311.2	HEAD'S BASE OF CHASSIS 1300L/1500	BASE DEL CABEZOTE - 1300L/1500	FUSCA - 1300L/1500
31	113.701.035.1	CHASSIS HEAD - 1200/1300	CABEZOTE ARMADO - 1200/1300	FUSCA - 1200/1300
34	113.805.591.3	CENTRAL FRONT PANEL	PANEL DELANTERO CENTRAL	FUSCA - 71/...
35	113.813.301.1	CENTRAL REAR PANEL	PANEL TRASERO CENTRAL	FUSCA - 71/...
36	BBA.813.301.B	CENTRAL REAR PANEL (W/1 ESCAPE)	PANEL TRASERO CENTRAL (1 SALIDA)	SPECIAL PCS/PZS ESPECIALES
37		CENTRAL REAR PANEL (W/2 ESCAPE)	PANEL TRASERO CENTRAL (2 SALIDA)	SPECIAL PCS/PZS ESPECIALES
38		HEAD TUNNEL	TUNEL DE LA CARROCERIA	FUSCA.../76
39	113.201.075.1	FUEL TANK	TANQUE DE GASOLINA	FUSCA - .../76
40	105.701.035.1	CHASSIS HEAD 1300L/1500	CABEZOTE DE LA CARROCERIA 1300L/1500	FUSCA 1300L/1500/BR/VT-81/....
45	113.201.075.8	FUEL TANK - 1300L/1500	TANQUE DE GASOLINA - 1300L/1500	FUSCA - 77/...
46	113.201.075	045E-FUEL TANK	045E-ESTANQUE DE BENCINA	SPECIAL PCS/PZS ESPECIALES
56		HEATING CHANNEL COMPL.W/AIR PAS.-RH	CAJA DE AIRE COMPL. C/PAS.AIRE -DER.	FUSCA
57		HEATING CHANNEL COMPL.W/AIR PAS-LH	CAJA DE AIRE COMPL. C/PAS.AIRE-IZQ.	FUSCA
59	113.701.059.Z	FLOOR - LH	PISO - IZQ.	FUSCA - .../76
60	113.701.060.Z	FLOOR - RH	PISO - DER.	FUSCA - .../76
61		FLOOR GUIDEWAY SEAT ASSEMBLY	CARRIL DEL PISO ARMADO	FUSCA - .../76
62	111.801.106.1	HEATING CHANNEL COMPL.W/O AIR PAS.-RH	CAJA DE AIRE COMPL. S/PAS.AIRE-DER.	FUSCA
63	111.801.105.1	HEATING CHANNEL COMPL.W/O AIR PAS.-LH	CAJA DE AIRE COMPL. S/PAS.AIRE - IZQ.	FUSCA
64		CHASSIS HEAD (MOUNTED) - 1200/1300	CABEZOTE ARMADO - 1200/1300	FUSCA - 1200/1300
65		CHASSIS HEAD (MOUNTED) - 1300L/1500	CABEZOTE ARMADO - 1300L /1500	FUSCA - 1300L/1500
66	113.701.131.1	CHASSIS FIXING BASE (NAPOLEON`S HAT)	BASE DE FIJACIÓN DEL CHASIS (SOMBRERO DE NAPOLEON)	FUSCA
67	113.701.059.2	FLOOR - LH	PISO - IZQ.	FUSCA - 76/79
68	113.701.060.2	FLOOR - RH	PISO - DER.	FUSCA - 76/79
69		FLOOR GUIDEWAY SEAT ASSEMBLY	CARRIL DEL PISO ARMADO	FUSCA - 77/86
70		CHASSIS HEAD 1200/1300 (MOUNTED)	CABEZOTE ARMADO 1200/1300	FUSCA 71.../96
71		CHASSIS HEAD 1300L/1500/1600 (MOUNTED)	CABEZOTE ARMADO 1300L/1500/1600	FUSCA 71.../96
72		BOTTOM PLATE TRANSVERSE EDGE, REAR,RIGHT	LONGARINA DEL PISO - DIR.	FUSCA
73		BOTTOM PLATE TRANSVERSE EDGE, REAR,LEFT	LONGARINA DEL PISO- IZQ.	FUSCA
88	113.831.052.3	DOOR - RH	PUERTA COMPLETA - DER.	FUSCA - .../76
89	113.831.051.3	DOOR - LH	PUERTA COMPLETA - IZQ.	FUSCA - .../76
90	113.831.052.6	DOOR - RH	PUERTA COMPLETA - DER.	FUSCA - 77/...
91	113.831.051.5	DOOR - LH	PUERTA COMPLETA - IZQ.	FUSCA - 77/...
92		HALF EXT. DOOR PANEL - RH	MEDIO PANEL EXT. DE PUERTA - DER.	FUSCA - .../76
93		HALF EXT. DOOR PANEL - LH	MEDIO PANEL EXT. DE PUERTA - IZQ.	FUSCA - .../76
94		EXT. DOOR PANEL - RH	PANEL EXT. DE PUERTA - DER.	FUSCA - .../76
95		EXT. DOOR PANEL - LH	PANEL EXT. DE PUERTA - IZQ.	FUSCA - .../76
96		EXT. DOOR PANEL - RH	PANEL EXT. DE PUERTA - DER.	FUSCA - 77/...
97		EXT. DOOR PANEL - LH	PANEL EXT. DE PUERTA - IZQ.	FUSCA - 77/...
98		HALF EXT. DOOR PANEL - RH	MEDIO PANEL EXT. DE PUERTA - DER.	FUSCA - 77/...
99		HALF EXT. DOOR PANEL - LH	MEDIO PANEL EXT. DE PUERTA - IZQ.	FUSCA - 77/...
100		INNER FRONT PANEL, COMPLETE 71/96	FRENTE ARMADA 71/96	FUSCA - 71/96
101	113.827.025.11	TAILGATE W/ GRATE	TAPA DEL MOTOR C/ REJILLA	FUSCA - 71/86
102	113.827.025.10	TAILGATE W/GRATE W/A FILTER OPENNING	TAPA DEL MOTOR C/REJ.C/ABERT P/FILTRO	FUSCA - 80/86
103	111.827.025.1	TAILGATE W/O GRADE	TAPA DEL MOTOR S/ REJILLA	FUSCA - 71/86
104	113.701.060.4	FLOOR - RH	PISO - DER.	FUSCA - 79/86
105	113.701.059.4	FLOOR - LH	PISO - IZQ.	FUSCA - 79/86
106		COMPLETE FLOOR RH	PISO COMPLETO DER.MOD.MEX.	FUSCA (MOD.MEX)
107		COMPLETE FLOOR LH	PISO COMPLETO IZQ. MOD.MEX.	FUSCA (MOD.MEX)
110	113.823.031.3	FRONT BONNET (HOOD) W/ GRADE	CAPO DELANTERO C/ REJILLA	FUSCA - 71/86
111	113.823.031.1	FRONT BONNET (HOOD) W/O GRADE	CAPO DELANTERO S/ REJILLA	FUSCA - 71/86
112	113.821.106.3	FRONT FENDER - RH	GUARDABARRO DELANTERO - DER.	FUSCA - 73/86
113	113.821.105.3	FRONT FENDER - LH	GUARDABARRO DELANTERO - IZQ.	FUSCA - 73/86
114	113.821.306.4	REAR FENDER - RH	GUARDABARRO TRASERO - DER.	FUSCA - 71/79
115	113.821.305.4	REAR FENDER - LH	GUARDABARRO TRASERO - IZQ.	FUSCA - 71/79
116	111.821.306.M	REAR FENDER - RH	GUARDABARRO TRASERO - DER.	FUSCA - 80/86 - (FAFA)
117	111.821.305.M	REAR FENDER - LH	GUARDABARRO TRASERO - IZQ.	FUSCA - 80/86 - (FAFA)
118	113.821.306.4	REAR FENDER - RH	GUARDABARRO TRASERO - DER.	FUSCA - .../70
119	113.821.305.4	REAR FENDER - LH	GUARDABARRO TRASERO - IZQ.	FUSCA - .../70
120		HEAD LIGHT BOWL BEETLE RH	SOPORTE DEL FARO - DER.	FUSCA
121		HEAD LIGHT BOWL BEETLE LH	SOPORTE DEL FARO - IZQ.	FUSCA
123	111.805.501 B	INNER FRONT PANEL,COMPLETE .../70	FRENTE ARMADA HASTA .../70	FUSCA .../70
124		SPARE WHEEL TROUGH SEDAN	PANEL DELANTERO INTERIOR VW .../77	FUSCA .../77
125		INNER FRONT PANEL	PANEL INTERIOR DE LA FRENTE ARMADA	FUSCA
985		NIPPLE OF FUEL TANK TO BEETLE 77/96	BOCAL DEL TANQUE DE GASOLINA	FUSCA 77/96
10101	113.827.025.8	101M-TAILGATE W/GRATE (MOD. MÉX.)	101M-TAPA DEL MOTOR C/REJ. (MOD. MÉX.)	SPECIAL PCS/PZS ESPECIALES
10110	113.823.031.3	110M-FRONT BONNET W/GRATE (MOD.MÉX.)	110M-CAPO DELANTERO C/REJ. (MOD.MÉX.)	SPECIAL PCS/PZS ESPECIALES
10111	113.823.031.1	111M-FRONT BONNET W/O GRATE(MOD.MÉX.)	111M-CAPO DELANTERO S/REJ. (MOD.MÉX.)	SPECIAL PCS/PZS ESPECIALES
10112	111.821.022.M	112LL-FRONT FENDER - RH	112LL-GUARDABARRO DELANTERO - DER.	SPECIAL PCS/PZS ESPECIALES
10113	111.821.021.M	113LL-FRONT FENDER - LH	113LL-GUARDABARRO DELANTERO - IZQ.	SPECIAL PCS/PZS ESPECIALES
10114	111.821.306.L	114L-REAR FENDER - RH	114L-GUARDABARRO TRASERO - DER.	SPECIAL PCS/PZS ESPECIALES
10115	111.821.305.L	115L-REAR FENDER - LH	115L-GUARDABARRO TRASERO - IZQ.	SPECIAL PCS/PZS ESPECIALES
10116	111.821.306.R	116M-REAR FENDER - RH (MOD.MÉX.)	116M-GUARDABARRO TRAS. -DER.(MOD.MÉX.)	SPECIAL PCS/PZS ESPECIALES
10117	111.821.305.R	117M-REAR FENDER - LH (MOD. MÉX.)	117M-GUARDABARRO TRAS. -IZQ. (MOD.MÉX.)	SPECIAL PCS/PZS ESPECIALES
20112	113.821.022.M	112FL-FRONT FENDER - RH	112FL-GUARDABARRO DELANTERO - DER.	SPECIAL PCS/PZS ESPECIALES
20113	113.821.021.M	113FL-FRONT FENDER - LH	113FL-GUARDABARRO DELANTERO - IZQ.	SPECIAL PCS/PZS ESPECIALES
20114	111.821.306.P	114PL-REAR FENDER - RH	114PL-GUARDABARRO TRASERO - DER.	SPECIAL PCS/PZS ESPECIALES
20115	111.821.305.P	115PL-REAR FENDER - LH	115PL-GUARDABARRO TRASERO - IZQ.	SPECIAL PCS/PZS ESPECIALES
30112	111.821.022.N	112LF-FRONT FENDER - RH	112LF-GUARDABARRO DELANTERO - DER.	SPECIAL PCS/PZS ESPECIALES
30113	111.821.021.N	113LF-FRONT FENDER - LH	113LF-GUARDABARRO DELANTERO - IZQ.	SPECIAL PCS/PZS ESPECIALES
40059A		HALF REAR FLOOR BEETLE LH	MEDIO PISO TRASERO IZQ.	FUSCA .../76
40060A		HALF REAR FLOOR BEETLE RH	MEDIO PISO TRASERO DER.	FUSCA .../76
40112	113.821.022.Q	112F-FRONT FENDER - RH	112F-GUARDABARRO DELANTERO - DER.	SPECIAL PCS/PZS ESPECIALES
40113	113.821.021.Q	113F-FRONT FENDER - LH	113F-GUARDABARRO DELANTERO - IZQ.	SPECIAL PCS/PZS ESPECIALES
50112	113.821.106.3	112M-FRONT FENDER - RH (MOD. MÉX.)	112M-GUARDABARRO DEL. - DER.(MOD.MÉX.)	SPECIAL PCS/PZS ESPECIALES
50113	113.821.105.3	113-FRONT FENDER - LH (MOD. MÉX.)	113M-GUARDABARRO DEL. - IZQ. (MOD.MÉX.)	SPECIAL PCS/PZS ESPECIALES
20106		PISO SIN EL SOPORTE DEL ASIENTO DER.	FLOOR WITHOUT SEAT SUPPORT RH	FUSCA (MOD.MEX)

20107		PISO SIN EL SOPORTE DEL ASIENTO IZQ.	FLOOR WITHOUT SEAT SUPPORT LH	FUSCA (MOD.MEX)
20108		SOPORTE FIJADOR DEL ASIENTO DER.	SEAT SUPPORT RH	FUSCA (MOD.MEX)
20109		SOPORTE FIJADOR DEL ASIENTO IZQ.	SEAT SUPPORT LH	FUSCA (MOD.MEX)
LINE/LINEA VOLKSWAGEN - KOMBI				
IGP	OEM	DESCRIPTION	DESCRIPCIÓN	APLICACION/APLICACIÓN
200	211.813.356.2	REAR ANGLE W/O WING HOLE - RH	CURVON TRASERO S/ VENTANA - DER.	KOMBI FURGÃO - 76/...
201	211.813.355.2	REAR ANGLE W/O WING HOLE - LH	CURVON TRASERO S/ VENTANA - IZQ.	KOMBI FURGÃO - 76/...
202	204.813.356.1	REAR ANGLE W/ WING HOLE - RH	CURVON TRASERO C/ VENTANA - DER.	KOMBI STD. - 76/...
203	204.813.355.1	REAR ANGLE W/ WING HOLE - LH	CURVON TRASERO C/ VENTANA - IZQ.	KOMBI STD. - 76/...
204	231.827.025.6	ENGINE COVER	TAPA DEL MOTOR	KOMBI CLIPPER- .../08-82
205	231.827.023.3	ENGINE COVER	TAPA DEL MOTOR	KOMBI CLIPPER- 09-82/...
220	211.809.500.1	FRONT FENDER - RH	GUARDABARRO DELANTERO - DER.	KOMBI - .../75
221	211.809.499.1	FRONT FENDER - LH	GUARDABARRO DELANTERO - IZQ.	KOMBI - .../75
252		EXT. DOOR PANEL - RH	PANEL EXT. DE PUERTA - DER.	KOMBI CLIPPER - 76/96
253		EXT. DOOR PANEL - LH	PANEL EXT. DE PUERTA - IZQ.	KOMBI CLIPPER - 76/96
254		EXT. DOOR PANEL - RH	PANEL EXT. DE PUERTA DER.	KOMBI CLIPPER - 94/...
255		EXT. DOOR PANEL - LH	PANEL EXT. DE PUERTA IZQ.	KOMBI CLIPPER - 94/...
256	APS.805.033	FRONT PANEL W/O WINDOW BOARD	PANEL FRONTAL	KOMBI CLIPPER
257		FRONT PANEL W/O WINDOW BOARD TYPE 2 KTL	PANEL FRONTAL T2	T2
258		FRONT PANEL W/O WINDOW BOARD	PANEL FRONTAL	KOMBI CARAT 97/...
259		FRONT PANEL W/O WINDOW BOARD 97/...	PANEL FRONTAL 97/...	KOMBI CARAT 97/...
LINE/LINEA - VOLKSWAGEN (GOL/VOYAGE/PARATI/SAVEIRO)				
IGP	OEM	DESCRIPTION	DESCRIPCIÓN	APLICACION/APLICACIÓN
504	302.821.022.3	FRONT FENDER - RH	GUARDABARRO DELANTERO - DER.	SAVEIRO - 80/83
505	302.821.021.4	FRONT FENDER - LH	GUARDABARRO DELANTERO - IZQ.	SAVEIRO - 80/83
508	305.821.022.10	FRONT FENDER - RH	GUARDABARRO DELANTERO - DER.	SAVEIRO - 87/90
509	305.821.021.10	FRONT FENDER - LH	GUARDABARRO DELANTERO - IZQ.	SAVEIRO - 87/90
510	305.813.301.1	REAR PANEL	PANEL TRASERO	GOL - 80/86
513	377.813.301	REAR PANEL	PANEL TRASERO	GOL-95/99
514	305.805.571.1	FRONT PANEL	PANEL DELANTERO	SAVEIRO - 80/84
515	305.821.021.13	FRONT FENDER - LH	GUARDABARRO DELANTERO - IZQ.	SAVEIRO - 91/94
516	305.821.022.12	FRONT FENDER - RH	GUARDABARRO DELANTERO - DER.	SAVEIRO - 91/94
517	305.813.301.2	REAR PANEL	PANEL TRASERO	GOL - 87/94
518	377.803.905	REAR PANEL REINFORCEMENT	REFUERZO PANEL TRASERO	GOL 99/05
522	303.805.571.1	FRONT PANEL	PANEL DELANTERO	SAVEIRO - 84/86
523	305.823.031.3	FRONT BONNET (HOOD)	CAPO DELANTERO	SAVEIRO - 87/90
524	305.823.031.4	FRONT BONNET (HOOD)	CAPO DELANTERO	GOL/SAVEIRO/PARATI/GACEL 91/94
525		EXT. DOOR PANEL - LH	PANEL EXT. DE PUERTA - IZQ.	SAVEIRO - 87/94
526		EXT. DOOR PANEL - RH	PANEL EXT. DE PUERTA - DER.	SAVEIRO - 87/94
527	26.103.601	ENGINE OIL PAN	CARTER DE ACEITE DEL MOTOR	GOL/PAS/VOY/PAR/SANT. - 85/...
528	302.821.022.3	FRONT FENDER - RH	GUARDABARRO DELANTERO - DER.	SAVEIRO - 84/86
529	302.821.021.4	FRONT FENDER - LH	GUARDABARRO DELANTERO - IZQ.	SAVEIRO - 84/86
530		EXT. DOOR PANEL - RH	PANEL EXT. DE PUERTA - DER.	SAVEIRO - 80/86
531		EXT. DOOR PANEL - LH	PANEL EXT. DE PUERTA - IZQ.	SAVEIRO - 80/86
532	305.823.031.1	FRONT BONNET (HOOD)	CAPO DELANTERO	SAVEIRO - .../86
533		HALF EXT. REAR SIDE - LH	MEDIA LATERAL TRAS. EXTERNA - IZQ.	GOL - .../86
534		HALF EXT. REAR SIDE - RH	MEDIA LATERAL TRAS. EXTERNA - DER.	GOL - .../86
535		HALF EXT. REAR SIDE - LH	MEDIA LATERAL TRAS. EXTERNA - IZQ.	GOL - 87/94
536		HALF EXT. REAR SIDE - RH	MEDIA LATERAL TRAS. EXTERNA - DER.	GOL - 87/94
537	305.805.571.18	FRONT PANEL	PANEL DELANTERO	SAVEIRO - 87/90
538	305.805.571.A	FRONT PANEL	PANEL DELANTERO	SAVEIRO - 91/94
539		FRONT BOTTOM PANEL	PANEL DELANTERO INFERIOR	SAVEIRO - 80/83
540		FRONT BOTTOM PANEL	PANEL DELANTERO INFERIOR	SAVEIRO - 84/86
541		FRONT BOTTOM PANEL	PANEL DELANTERO INFERIOR	GOL/PARATI 87/90
542		FRONT BOTTOM PANEL	PANEL DELANTERO INFERIOR	GOL/PARATI 91/94
546	305.803.703.2	REINFORCEMENT REAR PANEL	REFUERZO PANEL TRASERO	GOL - 80/86
547	305.803.407.4	REINFORCEMENT REAR PANEL	REFUERZO PANEL TRASERO	GOL - 87/94
553		HALF FRONT INNER CASTING - LH	MEDIA LATERAL DEL. INTERNA - IZQ.	SAVEIRO - 84/86
554		HALF FRONT INNER CASTING - RH	MEDIA LATERAL DEL. INTERNA - DER.	SAVEIRO - 84/86
555		HALF FRONT INNER CASTING - LH	MEDIA LATERAL DEL. INTERNA - IZQ.	SAVEIRO - 87/90
556		HALF FRONT INNER CASTING - RH	MEDIA LATERAL DEL. INTERNA - DER.	SAVEIRO - 87/90
557	APS.809.103	HALF FRONT INNER CASTING - LH	MEDIA LATERAL DEL. INTERNA - IZQ.	SAVEIRO - 91/94
558	APS.809.104	HALF FRONT INNER CASTING - RH	MEDIA LATERAL DEL. INTERNA - DER.	SAVEIRO - 91/94
559	377.805.571.A	FRONT PANEL	PANEL DELANTERO	GOL/PARATI - 95/...
560	377.823.031.B	FRONT BONNET (HOOD)	CAPO DELANTERO	GOL/PARATI - 95/...
561	377.821.105	FRONT FENDER - LH	GUARDABARRO DELANTERO - IZQ.	GOL/PARATI - 95/...
562	377.821.106	FRONT FENDER - RH	GUARDABARRO DELANTERO - DER.	GOL/PARATI - 95/...
563		LUGGAGE COMPARTMENT'S FLOOR	PISO DEL PORTAMALETA	GOL/PARATI - 95/...
564		LUGGAGE COMPARTMENT'S FLOOR	PISO DEL PORTAMALETA	GOL/PARATI - 95/...
568		HALF EXT. REAR SIDE - RH	MEDIA LAT. TRAS. EXT. DER. 2P	GOL - 84/86
569		HALF EXT. REAR SIDE - LH	MEDIA LAT. TRAS. EXT. IZQ. 2P	GOL - 84/86
570	305.809.844	HALF EXT. REAR SIDE - RH	MEDIA LAT. TRAS. EXT. DER. 2P	GOL - 87/94
571	305.809.843	HALF EXT. REAR SIDE - LH	MEDIA LAT. TRAS. EXT. IZQ. 2P	GOL - 87/94
573	377.805.581	UPPER FRONT CROSS MEMBER	TRAVESSA SUPERIOR FRONTAL	GOL/PARATI - 95/...(BIGODE)
574	377.809.606.B	HALF EXT. REAR SIDE - RH	MEDIA LAT. TRAS. EXT. DER. 2P	GOL - 95/96
575	377.809.605.B	HALF EXT. REAR SIDE - LH	MEDIA LAT. TRAS. EXT. IZQ. 2P	GOL - 95/96
576	377.809.606.AC	HALF EXT. REAR SIDE - RH	MEDIA LAT. TRAS. EXT. DER. 2P	GOL - 97/...
577	377.809.605.AC	HALF EXT. REAR SIDE - LH	MEDIA LAT. TRAS. EXT. IZQ. 2P	GOL - 97/...
800	377.823.031.C	FRONT HOOD	CAPO DELANTERO	GOL 2000
801	377.805.571.B	FRONT PANEL	PANEL DELANTERO	GOL/PARATI - 99/...
802	377.821.106.B	FRONT FENDER RH	GUARDABARRO DELANTERO DER.	GOL/PARATI - 99/...
803	377.821.105.B	FRONT FENDER LH	GUARDABARRO DELANTERO IZQ.	GOL/PARATI - 99/...
827		EXTERNAL REAR SIDE GOL GIII LH (2 DOORS)	MEDIA LATERAL TRAS. EXT. GOL GIII IZQ (2P)	GOL / VOYAGE / PARATI / SAVEIRO 99/..
828		EXTERNAL REAR SIDE GOL GIII RH (2 DOORS)	MEDIA LATERAL TRAS. EXT. GOL GIII DER. (2P)	GOL / VOYAGE / PARATI / SAVEIRO 99/...
829		EXTERNAL REAR SIDE GOL II LH (4 DOORS)	MEDIA LATERAL TRAS. EXT. GOL GII IZQ. (4P)	GOL / VOYAGE / PARATI / SAVEIRO 95/99
830		EXTERNAL REAR SIDE GOL II RH (4 DOORS)	MEDIA LATERAL TRAS. EXT. GOL GII DER. (4P)	GOL / VOYAGE / PARATI / SAVEIRO 95/99
831		EXTERNAL REAR SIDE GOL III/IV LH (4 DOORS)	MEDIA LATERAL TRAS. EXT. GOL GII/IV IZQ. (4P)	GOL / VOYAGE / PARATI / SAVEIRO 95/...
832		EXTERNAL REAR SIDE GOL III/IV RH (4 DOORS)	MEDIA LATERAL TRAS. EXT. GOL GII/IV DER. (4P)	GOL / VOYAGE / PARATI / SAVEIRO 99/...